Model 357 Scale Setup Procedure



- 1. Place scale platform on Plastic Plate
- 2. Place Basket on scale platform
- 3. Place compensation weight in basket
- 4. Plug in the remote pushbutton.
- 5. Turn on scale by pushing the ZERO button
- 6. Scale will come on with a weight of Zero and the Zero Icon will be on.



7. Press the HOLD button several time until the HOLD Icon is on.



8. Ready to weigh



Scale Weighing Procedure

- 1. Remove compensation weight from basket and replace with bag of fish.
- 2.Once the weight is stabilized the display will lock. An icon on the screen will remind the scale operator the display is in HOLD mode.
- 3. Remove the bag of fish. The weight on the screen will remain even after the bag is removed.
- 4. The scale operator will read the weight to be recorded when it is in the HOLD mode.



- 5. Replace the compensation weight.
- 6. Release the HOLD function, press the remote pushbutton.
- 7. The scale will be at zero and the ZERO icon will indicate when you are ready to weigh the next bag of fish.

